



# Wireless Control Options...



Wireless Switch  
Part: LS30060WSI



Picture Touch Controller  
Part: LS30400WTS



Long-range remote  
Part: LS30050LRC



iPhone App (free)